


# User Manual


## What's in the Box?




Key puller x1




Cable x1



Keyboard x1




Note: This user manual is available for UK and US keyboards.




## Lighting Mode

	<ol style="list-style-type: none"> <li>① Aggregate</li> <li>② Raining</li> <li>③ Wave</li> </ol>
	<ol style="list-style-type: none"> <li>① Byte</li> <li>② Single Ripple</li> <li>③ Full Ripple</li> </ol>
	<ol style="list-style-type: none"> <li>① Circular Running</li> <li>② Snake Running</li> </ol>
+	<ol style="list-style-type: none"> <li>① Instant extinguished</li> <li>② Gradually extinguished</li> </ol>
	<ol style="list-style-type: none"> <li>① Breathing</li> <li>② Dispersal</li> </ol>
	Full backlight
	<b>Custom mode:</b> A: Press FN+F12: F1-F5 keys are flashing to access in custom mode. B: Optionally select the F1-F5 key to record the settings. C: Press FN+F12 to save the settings.

1




Type-C cable




A87 Mechanical keyboard

2




Three cable outlets



Type-C connect way

## Setting Up




Connect the keyboard cable to a USB port on your PC, and it is plug-and-play.  
(Example: DAREU A87 Mechanical Keyboard)




Applicable to all PC devices

## Magnetic top cover


1




2



3



Download the driver from DAREU website if needed.




1

Driver interface

2

Marco interface



# A87 Series

Factory: Dongguan Torgan Electronics Technology Co.,Ltd.  
Factory ADD: No.262 Shidan Road, 3rd industrial park, Juzhou Area ,  
Shijie Town, Dongguan City, Guangdong Province, China.

Tel.: +86 769 8630 8806 Fax: +86 769 8630 8826

Email: [Info@dareu.com](mailto:Info@dareu.com) [CS@dareu.com](mailto:CS@dareu.com)

Web: [www.dareu.com](http://www.dareu.com)